

Quick Reference Card

DNR

XTL 1500 Mobile



Talkgroup/Channel Select

Received Signal Strength Indicator (RSSI)

Radio on/off/volume

Quick Reference Card

DNR

XTL 1500 Mobile

SHUBIE
FIRE CTL
FIRE EQP
AVIATION
YAR SHEL
ANNA DIG
KINGS
KENTWDLF
LUN QUEN
HAL WEST
HAL EAST
COLHANTS
CUMBRND
PICTOU
GUYS ANT
RICHMOND
INN VCTR
C B CO
STRATLRN
WDLF PK
DNRFLEET
FOR HLTH
INVENTORY
GEOLOGY

DNR OPS1
DNR OPS2
SHUBIE
SX DNR
DNR-VFD1
DNR-VFD2
DNR-VFD3
DNR-VFD4
NS MA 1
NS MA 2
NS MA 3
NS MA 4
NS MA 5
NS MA 6
NS MA 7
NS MA 8
COMMON 1
COMMON 2
CONV RP1
CONV RP2
SX ALL 1
SX ALL 2
SX ALL 3
SX DNR